AUTOMATION INDIA



Pre Start Alarm

As per safety norm Worker working near conveyor belt should be made alert with clear and distinct sound before conveyor belt is started The alarm should work for at least p30 seconds so that the work rs near the belt should move to the safety place. This time can be increased depending upon the situations. This ty e of Pre-St rt Alarm must be installed in every conveyer belt.

In our Pr -Start Alarm, we have used the audio as well as visual indicator for the night. We hold the **ISO 9001:2015**, Quality Assurance Certificate for our product range

WORKING On THE PRE-START ALARM:

To start the conveyor belt first we have to switch 'ON' the Pre-start Alarm. This alarm will give HUMAN sound to alert t e surrounding people for 30 seconds, after that this alarm will start the

Conveyor Belt. In order to withstand hazardous mini g

working conditions total circuit is embedded in water proof solution w h i c h makes it water and dust proof and a foreign matter

ill not damage it. As far as visualization goes, we have used 10 mm focus type Red Light fitting Diodes. This results in maximum intensity of red light. For audio, the horn type speakers of high quality which delivers sound of 300 dB are used, so that sound so loudly can easily be heard by anybody standing within the area of minimum 100 meters (500 meters) distance. The speakers are specially designed for mining condition are made robust, and completely dust and water proof.